



installation

De-signage

In this package you should receive;

1 x Plaque

1 x Template

Screw pack containing; plugs and screws

Panel supports

Tools Required

Screw Pack (provided), Tape Measure, Drill, Spirit Level and a Pozi head Screw Driver, Alain Key (provided with SX 120, SX 175, SX 400, RX113, RX362, RX226, RX118, RX 351 & RX400 products only).

Step 1

Drill wall using a 4mm drill bit followed by 5mm drill bit (please read tips overleaf), as indicated on the template.

Step 2

Insert wall plug provided.

Screw the locator to wall using the screw provided (1 1/4 inch No.6 Pozi Head).

Step 3

Position the pre-drilled holes in the perspex panel to the fixed locator and tighten the 2nd part of the locator by hand (or Alain key) until secure.

TIPS

When mounting your plaque, please use a leveled area to ensure the best fixing.

DO NOT use brick joints as an mounting position.

Use Solid brickwork to ensure a secure fixing and to allow the locators to fit flush with the brick work.

For ease and accuracy of drilling De/signage suggests you use a 4mm or smaller masonry drill bit, and then use a 5mm drill bit to complete your hole, this procedure will stop your masonry drill bit from drifting, which can knock your locators out of alignment.

Please ensure your template has been taped into position before drilling, and the position is checked using a spirit level.

After CARE

Clean perspex plaques and letters with a soft cloth and soapy water. DO NOT clean this product with any abrasives or solutions which may scratch or discolour surfaces.